


ibico®**EPK 21** (27170)

Binding Systems

Elektro Kombo*The High-Speed Punch and Bind System***SPECIAL FEATURES:**

- Electric foot pedal punch operation for easy, hands free punching
- Binds up to 2" thick or 425 sheets*
- 21 disengageable punching dies; 25 sheets per punch
- Electric punch and manual plastic binding system
- Punch 20,000 sheets per hour; bind 250 books per hour
- For books up to 12" in length
- Open throat construction allows punching of oversized documents
- 4 position depth selector varies the distance between the punched hole to the paper's edge from $\frac{1}{8}$ " to $\frac{3}{8}$ " – larger documents require larger margins
- Adjustable side guide for proper paper and cover alignment
- Circuit breaker prevents power overloads
- Rugged, all metal construction for increased durability
- Progressive cutting dies for precise punching and little paper dust
- Variety of textured covers and colored combs available
- UL listed / CSA certified
- Dimensions: 19 $\frac{1}{2}$ " W x 15 $\frac{1}{2}$ " D x 12 $\frac{1}{2}$ " H
- Weight: 52.0 lbs.

**APPLICATIONS:**


- Client Presentations
- Proposals
- Important Letters
- Client Reviews
- Annual Reports
- Corporate Identity Pieces

LIMITED ONE YEAR WARRANTY**RUGGED METAL CONSTRUCTION**

*Standard 20lb. bond paper

ibico®**EPK21
Elektro Kombo®**

Binding Systems


**Operation
Manual****Advanced Document
Systems & Supply, Inc.**

Phone : 800-808-2377

Fax : 888-237-7329

SET-UP

- 1** Attach the handle to the machine on the left side and push in firmly to secure.
- 2** Turn power switch on (location on right side of machine). Allow 30 seconds for motor to reach full speed. In cold weather, allow machine to reach room temperature before turning power on.




PUNCHING

- 3** The black dial on the right side of the machine is the 4-position depth selector used to vary the distance between the punched hole and the paper's edge from 1/16" to 3/16". This feature is ideal for thicker documents that require wider margins for easy page turning and more secure binding.
- 4** EPK21 has 21 disengagable dies which makes it possible to punch virtually any length document. To punch the standard 19-hole pattern for 11" paper, pull the first die and last die (#1 and #21 on the back punch diagram).



- 5** Put sheets flush into the machine. (Use side guide for side adjustment).
- 6** Step on the foot pedal to punch.




7
Regular empty
drawer of clippings.

BINDING

- 8** The black knob on the left side of the machine can be set to lock in comb opening settings. The handle stops automatically at the same position each time for quicker operation during long binding runs.
- 9** Insert binding comb open side up, between the tines of the metal rake.




Turn clockwise to open, pull handle to desired opening, then turn knob counter-clockwise to lock.




- 10** Push handle forward to open comb.




- 11** Insert paper vertically, cover facing the user.



- 12** Lay paper horizontally (or flat), then return handle to vertical position to close comb.



- 13** Remove book vertically.



- 14** To revise a document, simply place bound document into the metal rake then repeat Steps 9 & 10. Remove or add sheets as required. Repeat Steps 11 through 13.